


O'Hare International Airport

Advanced Airfield Drivers Map

Airfield Map, current from June 4th, 2021 to June 20th, 2021



LEGEND

- Service Road
- Restricted CDA Access Roads
- Restricted Fire Access Roads
- Aircraft Design Group VI Restricted Areas
- 1 Crash Fire Rescue Stations
- Fire Burn Pit Training Facility
- 2 Airfield Security Post Locations
- Areas Under Construction
- Closed AOA Pavement (for construction)

ATC Frequencies

9L-27R:	128.15
9C-27C:	121.15
9R-27L:	126.90
10L-28R (Primary):	132.70
10L-28R (Alternate):	120.75
10C-28C:	120.75
10R-28L:	133.00
4L-22R:	126.90
4R-22L:	120.75
CDF GC Inbound:	131.05
CDF GC Outbound:	130.75
GC North Tower:	124.125
GC North of 10L-28R:	121.90
GC South of 10C-28C:	118.05
GC btn 10L & 10C:	120.75
Outbound Ground:	121.75
Alternate Ground:	118.45
SE/SC/SW Cargo:	122.95
Emergency Freq:	119.25
ATIS:	135.40
"YY" Roller Gates:	122.90

Map to be used for reference ONLY
Not to be used for aircraft or taxi navigation
It is the responsibility of the user to ensure they have the most accurate airport reference map prior to driving or taxiing on the airfield

ASSET 2009 - 2021
12 Years of Aviation Safety
www.oharetraining.com www.ordsafe.com

Airfield Map, current from June 4th, 2021 to June 20th, 2021



Ground Control: 124.125

Ground Control: 124.125

Ground Control: 121.90

CDF Ramp
Inbound: 131.05
Outbound: 130.75

Ground / Local Control:
120.75

Areas highlighted in red between 10L-28R and 10C-28C will utilize the same frequency of 120.75 for both Local and Ground control.

Ground Control:
118.05

ATC Frequencies

9L-27R:	128.15
9C-27C:	121.15
9R-27L:	126.90
10L-28R (Primary):	132.70
10L-28R (Alternate):	120.75
10C-28C:	120.75
10R-28L:	133.00
4L-22R:	126.90
4R-22L:	120.75
CDF GC Inbound:	131.05
CDF GC Outbound:	130.75
GC North Tower:	124.125
GC North of 10L-28R:	121.90
GC South of 10C-28C:	118.05
GC btn 10L & 10C:	120.75
Outbound Ground:	121.75
Alternate Ground:	118.45
SE/SC/SW Cargo:	122.95
Emergency Freq:	119.25
ATIS:	135.40
“YY” Roller Gates:	122.90

**Map to be used for
reference ONLY
Not to be used for
aircraft or taxi navigation**

*It is the responsibility of the
user to ensure they have the
most accurate airport reference map
prior to driving or taxiing on the airfield*